RBR

Small loggers for Temperature, Depth and DO **One or Two Channel Submersible Recorders**

These single and dual channel loggers set the standard for submersible measurements. For single channel temperature see the TR-1060P data sheet for even better cost/performance.

General Specifications

Case Size:	<270mm x 38mm diameter
Material:	Delrin® (acetal copolymer)
	Titanium (for up to 10,500m)
Memory:	8Mbyte Flash (2,400,000 samples)
Power:	Two CR123A Lithium (3V) Standard
	camera batteries or external power (6 to
	15 V) via optional connector.
	Battery power sufficient for 2,400,000
	readings or three years of operation
Weight:	310g in air 45g in water (Delrin®)
	500g in air 220g in water (titanium)
Depth ratings:	740m (Delrin® housing)
	10,500m Titanium, temperature
	10,000m Titanium, depth
	2,000m Titanium, with DO
Calibration:	NIST traceable standards
Communications:	RS-232/485 RF Modem control or
	GSM/CDMA modem
Download Speed:	~115,000 samples/minute
Clock Accuracy:	±32 seconds/year

Software

Integrated RBR Windows® software is available at no additional charge for all of our instruments. See reverse for further details or check our website for details, downloads and upgrades.



RBR Ltd.

27 Monk Street, Ottawa, ON Canada K1S 3Y7 Tel: +1 613 233-1621 Fax: +1 613 233-4100 info@rbr-global.com www.rbr-global.com

Temperature

Range:	-5 °C to 35 °C Standard range
5	-40°C to 50° Extended ranges
	To >300°C with special probes
Accuracy:	± 0.002 °C
	(ITS-90 and NIST traceable standards)
Resolution:	<0.00005 °C
Time Constant:	~3 sec (standard); or ~0.1 sec (option)
Drift:	~0.002°C/year - typical
Depth	
Pango	10/20/50/100/200/500/740/1000/

Range: 10/20/50/100/200/500/740/1000/ 2000/4000/6000/10,000m (dBar) ±0.05% full scale Accuracy: Resolution: <0.001% full scale Time Constant: < 10 msec Drift: ~0.1%/year - typical

Dissolved Oxvaen

Sensor:	Oxyguard DO522M18	
Range:	0 to 200%*	
Accuracy:	$\pm 2\% O_2$ saturation, over 5° to 25°*	
* These rep	resent the manufacturer's specifications.	
For further information on sensor performance please		
contact RBI	،	

Ordering Information

Temperature		
TR-1050P	See the TR-1060P;TR-1050Ti up to	
	10,500m	
Depth		
DR-1050P	10/20/50/100/200/500/740m	
DR-1050Ti	1,000/2,000/4,000/6,000/10,000m	
Dissolved Oxygen		
DO-1050P	Up to 740m; DO-1050Ti up to 2,000m	
Temperature and Depth		
TDR-2050P	10/20/50/100/200/500/740m	
TDR-2050Ti	1000/2000/4000/6000/10,000m	
Temperature and DO		
TDO-2050P	Up to 740m;TDO-2050Ti up to 2,000m	
Accessories: mooring clamps, support kits, DO sensor		
membranes, u/w connectors, desiccant packs.		
	1.4.1	

RBR Europe Ltd. 17 Cratlands Close, Stadhampton, Oxfordshire, OX44 7TU United Kingdom Tel/Fax: +44 (0)1865 890979 info@rbr-europe.com www.rbr-europe.com RBR

RBR Windows® Software Data Logger Software

The RBR Windows[®] software package has been designed for easy use while still providing the necessary features for logger programming, data retrieval and analysis. One piece of software does it all!

Features:

- Intuitive
- Graphical Display
- **Derived Units**
- Export to Matlab®
- **GPS** Integration
- Telemetry ready
- Setup cloning

RBR's Windows®-based data logger software includes a straightforward logger setup display menu that includes options for programming start and stop time, thresholding, sampling rates for both tides and waves (TWR-2050), burst rate, burst length, averaging, and batch programming.

Some basic analysis features are included that allow the user to review the data graphically. Data can also be saved in various file formats for easy import into third party software packages, such as Matlab® or Microsoft[®] Excel[®].

Derived Units

- Salinity (PSS-78)
- Depth
- Speed of Sound
- Density
- **Dissolved Oxygen**
- Specific Conductivity


Analysis of waves & wave spectra:

- Significant Wave Height
- Mean Period Significant Wave Period
- Total Energy

RBR Ltd.

27 Monk Street, Ottawa, ON Canada K1S 3Y7 Tel: +1 613 233-1621 Fax: +1 613 233-4100 info@rbr-global.com www.rbr-global.com





Logger programming is easily achieved by using the 'Setup' dialog, which allows the user to choose Start and End times, Sampling Rate, Averaging, Thresholding, as well as synchronize the logger with the PC clock. The setup dialog also indicates the expected battery and memory usage for the chosen deployment settings.

Re-calibration is done easily by entering the coefficients for each channel of the logger in the appropriate columns. These values are stored in the



logger, and a complete calibration history is always available at the click of a button. In order to reduce deployment error, a log file is automatically generated for all logger setup activity.

System Requirements

Operating System:
CPU:
RAM:
Communications:
Cost:

Windows® 95/98/ME/2000/XP/Vista x86 133Mhz or higher 128MB recommended At least 1 RS-232 serial port, or USB **RBR** Software is free.



RBR Europe Ltd.

17 Cratlands Close, Stadhampton, Oxfordshire, OX44 7TU United Kingdom Tel/Fax: +44 (0)1865 890979 info@rbr-europe.com www.rbr-europe.com